

KEYED NOTES: (FOR THIS SHEET ONLY)

- CLEAN CONDENSER COIL FREE OF DIRT AND DEBRIS FOR BOTH $\underline{\text{CH-1}}$ AND $\underline{\text{CH-2}}$.
- REPLACE EXISTING COMPRESSOR WITH A REMANUFACTURED FACTORY COMPRESSOR. PROVIDE THE COMPRESSOR WITH AN ADDITIONAL OIL FILTER. CHANGE FILTERS, DRIERS AND OIL FOR SYSTEM #1. START-UP AND TEST THE CHILLER AND NEW COMPRESSOR. AFTER THREE DAYS OF OPERATION TAKE AN OIL SAMPLE FOR TESTING BY A CERTIFIED LAB FOR PARTICULATE CONTAMINATION AND REPLACE THE OIL FILTER.

GENERAL NOTES:

- I. COORDINATE ALL WORK WITH OWNER INCLUDING SHUT DOWN TIMES AND DURATION.
- 2. ALL NEW EQUIPMENT SHALL BE COMPATIBLE WITH EXISTING CHILLER CH-2.
- 3. PROVIDE I YEAR PARTS AND LABOR WARRANTY ON THE NEW COMPRESSOR.
- 4. CONTRACTOR SHALL FIELD VERIFY MODEL AND SERIAL NUMBERS BEFORE ORDERING THE NEW COMPRESSOR.

Dafe No. Revision

yned 7059
wn Approved
Av Approved Approved

AIGN COUNTY NURSING HOME CHILLER REPAIR

Engineers and Associates, Inc.
Mechanical & Electrical Consulting Engineers
1615 South Neil Street
Champagon, Ilmuss 16820
Tel: (217) 386-0538 Fax: (217) 386-1092

Date MAY 4, 2017

Sheet
ME-1

SCALE: 1/8" = 1'-0"